

# ZEN / ZENITH Mk3 Quick Start Guide

## Thank you for buying our Music Server.


This quick start guide will show you how to get started with your new Music Server.

For more detailed information please visit our website https://innuos.com/support/

Should you have problems please contact <a href="mailto:support@innuos.com">support@innuos.com</a> and we'll be happy to assist you.


### Contents

1	ZEN/ZENith Mk3 Rear Panel Diagram · · · · · · · · · · · · · · · · · · ·	2
2	Box Contents · · · · · · · · · · · · · · · · · · ·	3
3	Connect Your System to Mains Power	4
4	Connect Your System to Your Home Network · · · · · · · · · · · · · · · · · · ·	5
5	Connect Network Audio Device to Streamer Port	6
6	Using Your System as a Player · · · · · · · · · · · · · · · · · · ·	7
7	Turn on Your System · · · · · · · · · · · · · · · · · · ·	8
8	Accessing Your Innuos Device · · · · · · · · · · · · · · · · · · ·	9
9	Update innuOS Software to the Latest Version · · · · · · · · · · · · · · · · · · ·	10
10	Adding Music to Your System · · · · · · · · · · · · · · · · · · ·	11
11	Streaming Services and Integrations	13
12	Turn Off Your System · · · · · · · · · · · · · · · · · · ·	14




- Mains Power Connector
- Fuse Box
- On/Off Switch

- 4 HDMI Output (Service Only)
- USB for Backup Drive (USB 3)
- USB DAC output (USB 2)
- Ethernet Input from Router
- 8 Ethernet Streamer Port




- Innuos ZEN / ZENith Mk3 Music Server 3 2m Ethernet Cable
- Mains Cable




## **Connect Your System to Your Home Network**

#### OPTION A Wired to the Internet Router




NOTE Optional - Not required for server operation




The Streamer Port provides a wired network connection for streamers, wireless speakers and other network audio products.

#### SETUP A Connect to a DAC/Amplifier via USB





Note: USB Cable not included. Requires DAC compatible with USB Audio Class 2.






Please press and release. Do not hold the front power button down.






#### OPTION A Rip CDs







Do not push the CD while it is being drawn in as this may cause it to jam or damage the optical drive.

#### **OPTION B** Import Digital Music









Please press and release. Do not hold the front power button down.

Notes:			



For more information and for the latest version of this quick start guide please visit: innuos.com/support